

Stable-iser Brush – Fitting Instructions

The Stable-iser Brush is designed to be securely fixed at the entrance of a horse or livestock stable. Correct installation ensures safe use and long service life.

Tools Required

- Drill and bits
 - Measuring tape, pencil/chalk line
 - Fixings (see below)
 - Screwdriver or socket driver
 - Spirit level
-

Installation Steps

1. Fitting into Timber Frame

- Position brush at threshold and mark hole positions through the backing.
 - Pre-drill pilot holes.
 - Fix using **galvanised coach screws** or **heavy-duty timber screws** (8–10 gauge, 50–75mm).
 - Check brush is level and flush.
-

2. Fitting into Metal Frame

- Place brush and mark holes.
 - Drill through metal with suitable bit (use cutting fluid if needed).
 - Secure with **galvanised bolts and nyloc nuts** or **self-drilling screws** (min. 8 gauge, 25–40mm).
 - Tighten securely and check alignment.
-

3. Fitting into Concrete

- Position brush and mark fixing points.
 - Drill with a masonry bit.
 - Use **galvanised masonry anchors, sleeve anchors, or concrete screws** (6–8mm, 50–75mm).
 - Secure firmly and confirm alignment.
-

Final Check

- Ensure fixings sit flush with countersunk holes.
 - Confirm brush is secure and level.
 - Test with a horse walking through for smooth action.
-

 **Tip:** Inspect fixings regularly and tighten if required.